

## Changing Out a Core on a Delta Push lock

Core Key



Tab in—turn key CW



Tab out—turn key CCW



- Insert core key and turn clockwise
- Pull the core from the lock housing
- Replacement core: insert key, turn key CW to withdraw tab, insert into lock housing, turn key CCW to lock in place, remove key

## Changing Out Master Lock on Narcotics Box



- Open the narc box
- Remove hex nuts (5/16 on newer 3/8 on older carts)
- Replace in reverse order